



Materials

SWAROVSKI ELEMENTS

| Product Group | Article No. | Amount | Size  | Color         | Color Code |
|---------------|-------------|--------|-------|---------------|------------|
| Beads         | 5328        | 2 pcs. | 4 mm  | Black Diamond | 215        |
| Beads         | 80201 03    | 2 pcs. | 15 mm | Black Diamond | 215        |

Supplies: One pair S/S blank earwire TierraCast 90-1120-00      6" S/S 20g wire (dead soft)  
 2 pcs. small oval jump rings TierraCast 01-0016-01

Instructions

- STEP 1: Cut the S/S wire into two equal pieces.
- STEP 2: Using one piece of wire from step 1, hammer the wire to flatten. Make sure that you flatten the wire evenly. Optional: using a texturizing hammer, tap onto the flattened wire to create a pattern. Repeat this step with the second piece of wire.
- STEP 3: Punch a hole in each end of both pieces of wire approximately 3-4 mm from the edge. The hole needs to be able to accommodate a piece of 20g wire.
- STEP 4: Using one piece of wire from step 3, with your fingers shape the wire into an elongated teardrop. Note: the ends of the wires with the punched out holes will need to line up – one hole over the other. Repeat for the second piece.
- STEP 5: Using one wire from step 4, slip on one BeCharmed Pavé Bead in Black Diamond.
- STEP 6: Open one small jump ring and attach to the holes in the wire keeping the holes one on top of the other. Close the jump ring. Repeat for the second wire.
- STEP 7: Slip one Bead (art. 5328, 4 mm, Black Diamond) onto the earwire blank. Create a simple loop. Repeat for the remaining pair.
- STEP 8: Gently open the loop created in step 7. Add the earring drop created in step 6. Making sure the earring is facing the front with the earwire lined up in the correct position, close the earwire loop. Repeat for the remaining pair.