



BECHARMING PAVÉ DANGLES EARRINGS

Materials

SWAROVSKI ELEMENTS

Product Group	Article No.	Amount	Size	Color	Color Code
Beads	5000	2 pcs.	4 mm	Crystal Luminous Green	001 LUMG
Beads	5328	12 pcs.	3 mm	Crystal AB	001 AB
Pendants	6010	4 pcs.	13x6.5 mm	Crystal Luminous Green	001 LUMG
Beads	80101 05	2 pcs.	14 mm	Crystal Luminous Green	001 LUMG

Supplies: 1 pair S/S earring blank TierraCast 90-1120-00
4 24 g S/S head pins TierraCast 01-0029-01

10" S/S small cable chain
4 small oval jump rings TierraCast 01-0016-01

Instructions

- STEP 1: Cut small cable chain into two 2" pieces and two 3" pieces. Set aside.
- STEP 2: Slip one Bead (art. 5000, 4 mm, Crystal Luminous Green) onto one S/S earring blank. Create a simple loop. Repeat step for other pair. Set aside.
- STEP 3: Slip one 2" chain through the hole of the Bead (art. 80101 05, Crystal Luminous Green). Open up the loop on one earwire from step 2. While holding the two ends of the chain together (the BeCharmed Pavé Bead is dangling from the chain at this point), attach the earwire to each end of the chain. Close the loop.
- STEP 4: Slip one 3" chain through the hole of the Bead (art. 80101 05, Crystal Luminous Green). Note: The 3" piece should be facing in the opposite direction from the 2" piece added in step 3. Set aside.
- STEP 5: Open one small oval jump ring. Slip on one Pendant (art. 6010, 13x6.5 mm, Crystal Luminous Green) and one end of the chain. Close the jump ring. Repeat this step for the other end of the 3" chain. Set aside.



STEP 6: Using one head pin, slip on one Bead (art. 5328, 3 mm, Crystal AB). Insert the headpin through the fourth link of chain from the earwire on the left side. Add one Bead (art. 5328, 3 mm, Crystal AB) onto the headpin and insert the headpin through the fourth link of chain from the earwire on the right side. Slip onto the headpin one Bead (art. 5328, 3 mm, Crystal AB). On the headpin should be one Bicone Crystal, one chain link from the left side of the chain, one Bicone Crystal, one chain link from the right side of the chain and one Bicone Crystal. The Crystals should look like they are laying on top of the chain from the front of the earring. Clip the headpin 6mm from the Bead. Using round nose pliers at the tip, begin to wind the headpin around the tool. You are creating a double loop. End the loop next to the Crystal Bead.
Note: Be careful not to wind it down too tight or you may break the crystal Bead.

STEP 7: Line up the 3" chain with the Pendant dangles to a position that pleases you. Using one head pin, slip on one Bead (art. 5328, 3 mm, Crystal AB). Take the headpin and insert it into the left chain approximately 10mm from the Bead hole of the BeCharmed Pavé Bead. Slip onto the headpin one Bead (art. 5328, 3 mm, Crystal AB). Take the headpin and insert it into a corresponding link on the right side of the chain. On the headpin should be one Bicone Crystal, one chain link from the left side of the chain, one Bicone Crystal, one chain link from the right side of the chain and one Bicone crystal. The Crystals should look like they are laying on top of the chain from the front of the earring. Clip the headpin 6mm from the Bead. Using round nose pliers at the tip, begin to wind the headpin around the tool. You are creating a double loop. End the loop next to the Crystal Bead.
Note: Be careful not to wind it down too tight or you may break the Crystal Bead.

STEP 8: Repeat steps 3 through 7 for the other pair.