



# TRICK OR TREAT NECKLACE

## Materials

### SWAROVSKI ELEMENTS

Product Group	Article No.	Amount	Size	Color	Color Code
Flat Backs No Hotfix	2058 (XILION Rose)	2 pcs.	SS10	Light Siam	227
Sew-on Stones	3700 (Marguerite Lochrose)	1 pc.	10 mm	Jet	280
Sew-on Stones	3700 (Marguerite Lochrose)	1 pc.	10 mm	Sun	248
Fancy Stones	4139 (Cosmic Ring)	8 pcs.	14 mm	Jet	280
Beads	5328 (XILION)	2 pcs.	2.5 mm	Jet	280
Beads	5328 (XILION)	3 pcs.	3 mm	Jet	280
Beads	5328 (XILION)	91 pcs.	4 mm	Jet	280
Beads	5328 (XILION)	6 pcs.	4 mm	Hyacinth	236
Beads	5328 (XILION)	6 pcs.	4 mm	Sunflower	292
Beads	5328 (XILION)	6 pcs.	4 mm	White Alabaster	281
Beads	5328 (XILION)	12 pcs.	5 mm	Hyacinth	236
Beads	5328 (XILION)	13 pcs.	5 mm	Sunflower	292
Beads	5328 (XILION)	3 pcs.	5 mm	White Alabaster	281
Beads	5540 (Artemis)	1 pc.	12 mm	Jet	280
Beads	5714 (Star)	1 pc.	8 mm	Jet	280
Pendants	6902 (Zinnia)	1 pc.	16.5x25 mm	Jet	280

Supplies: 1 TierraCast toggle set 94-6151-13  
 15 TierraCast round jump rings 01-0020-13  
 2 3 mm crimp covers  
 6" 24 gauge black Artistic Wire  
 Two-part epoxy glue

6 TierraCast oval jump rings 01-0018-13  
 2 2x2 crimp beads  
 20" 0.015 Beadalon Stringing Wire  
 24" 26 gauge silver Artistic Wire

### Instructions - Bat Pendant Drop

- STEP 1: Mix two-part epoxy glue as instructed on package.
- STEP 2: Using a toothpick, place 2 small dots of mixed glue near center of Pendant art. 6902 Jet from the SWAROVSKI ELEMENTS assortment (see picture for correct way to lay Pendant).
- STEP 3: Apply a small amount of beeswax to the end of a clean toothpick. Pick up one Flat Back No Hotfix art. 2058 Light Siam using the tip of the beeswax toothpick and place on one of the glue dots. Repeat with second Flat Back No Hotfix art. 2058 Light Siam.
- STEP 4: Allow glue to dry for recommended time on glue package. Clean any glue residue with a Q-tip dipped in acetone.
- STEP 5: Open 5 round jump rings and 2 oval jump rings.
- STEP 6: Attach one round jump ring to bat and close. Attach two round jump rings to Swarovski Fancy Stone art. 4139 Jet and close. Repeat for second Fancy Stone and set aside.
- STEP 7: Using the oval jump ring attach to round ring on bat and one round ring on Swarovski Fancy Stone. Close ring. Using second oval jump ring attach the two Fancy Stones together by connecting the round jump rings. Set this pendant aside.

### Instructions - Crystal Corn Pendant Drop

- STEP 1: Using the 24" gauge wire, load onto wire 13 Beads art. 5328 5 mm Sunflower from the SWAROVSKI ELEMENTS assortment. Moving 6 Beads off to one side and keeping the 7 remaining Beads in the center of the wire, take the wire exiting from the 6 Beads and string the wire through all 7 Beads. (Note: the wire tails should be exiting in opposite directions from the 7 Beads. The 6 Beads should be sitting on top and in between the 7 Beads. It is important to keep tension on the wire when weaving.)
- STEP 2: String onto one of the wire sides, 5 XILION Beads art. 5328 5 mm Hyacinth. Take the wire from the opposite side and string through the 5 Beads. (Note: the wire tails should be exiting in opposite directions from the 5 Beads and the 5 Beads should be sitting on top and in between the 6 Beads art. 5328 5 mm Sunflower from the previous step.)
- STEP 3: Repeat step 2 using 4 Beads art. 5328 5 mm Hyacinth.
- STEP 4: Repeat step 3 using 3 Beads art. 5328 5 mm Hyacinth.
- STEP 5: Repeat step 4 using 2 Beads art. 5328 5 mm White Alabaster.
- STEP 6: Repeat step 5 using one Bead art. 5328 5 mm White Alabaster.
- STEP 7: Take both tails of the remaining wire and working the wire together create a wire wrapped loop.
- STEP 8: Open 6 round jump rings and 3 oval jump rings.

### Instructions - Crystal Corn Pendant Drop

- STEP 9: Attach two round jump rings to Fancy Stone art. 4129 Jet and close. Repeat for other two Fancy Stones and set aside.
- STEP 10: Using the oval jump ring attach the corn to one round jump ring on a Fancy Stone and close. Using second oval jump ring attach the two Fancy Stones together by connecting to the round jump rings. Repeat for third Fancy Stone and set this pendant aside.

### Instructions - Witches Hat Pendant Drop

- STEP 1: Cut the 6" piece of wire into two 3" pieces. Approximately 3 mm from the end of each piece of wire, use chain nose pliers to fold up a bend. (Note: using this technique you will create headpins.)
- STEP 2: Using two pieces of wire from step 1, slide on one Sew-on Stone art. 3700 10mm Jet, one Fancy Stone art. 4139 14mm Jet, one Sew-on Stone art. 3700 10mm Sun and one Bead art. 5540 12mm Jet.
- STEP 3: Keep the two wires apart; on one wire slide on one Bead art. 5328 4mm Jet. On the second wire, slide 3 Beads art. 5328 3mm Jet and 2 Beads art. 5328 2.5mm Jet. Cut the wire 10mm from the last Bead art. 5328 2.5mm Jet. Using round nose pliers, turn a loop towards the Bead art. 2.5mm Jet – at least 1.5 to 2 rotations.
- STEP 4: Using the second wire that has the Bead art. 5328 4mm Jet on it; turn a loop and then wrap the wire around the Bead art. 5328 4mm Jet and create a wire wrap between the Bead 5328 4mm Jet and the Bead art. 5540 12mm Jet. Trim tail and tuck next to coil made.
- STEP 5: OPTIONAL: Using a 3" piece of wire, wire wrap Bead art. 5714 8mm Jet and attach to the coiled loop made at the end of the Bead art. 5328 2.5mm Jet.
- STEP 6: Shape the point of the hat by gently curving the wire (see picture).
- STEP 7: Open 4 round jump rings and 1 oval jump ring.
- STEP 8: Attach one round jump ring to the loop on the witches hat and the Fancy Stone and close. Attach another round jump ring to the Fancy Stone and close. Attach two round jump rings to second Fancy Stone art. 4139 14mm Jet and close.
- STEP 9: Using an oval jump ring attach the two Fancy Stones together by connecting the round jump rings. Set this pendant aside.

### Instructions - Necklace

- STEP 1: Using beading wire string on 40 Swarovski XILION Beads art. 5328 4mm Jet, one Bead art. 5328 4mm White Alabaster, one Bead art. 5328 4mm Hyacinth, one Bead art. 5328 4mm Sunflower, one Bead art. 5328 4mm Jet.
- STEP 2: Add bat pendant drop. Add one XILION Bead art. 5328 4mm Jet, one Bead art. 5328 4mm Sunflower, one Bead art. 5328 4mm Hyacinth, one Bead art. 5328 4mm White Alabaster, 2 Beads art. 5328 4mm Jet, one Bead art. 5328 4mm White Alabaster, one Bead art. 5328 Hyacinth, one Bead art. 5328 4mm Sunflower and one Bead art. 5328 4mm Jet.
- STEP 3: Add candy corn pendant drop. Add one XILION Bead art. 5328 4mm Jet, one Bead art. 5328 4mm Sunflower, one Bead art. 5328 4mm Hyacinth, one Bead art. 5328 4mm White Alabaster, two Beads art. 5328 4mm Jet, one Bead art. 5328 4mm White Alabaster, one Bead art. 5328 4mm Hyacinth, one Bead art. 5328 4mm Sunflower and one Bead art. 5328 4mm Jet.
- STEP 4: Add witches hat pendant drop. Add one Bead art. 5328 4mm Jet, one Bead art. 5328 4mm Sunflower, one Bead art. 5328 4mm Hyacinth, one Bead art. 5328 4mm White Alabaster, and 40 Beads art. 5328 4mm Jet.
- STEP 5: Using crimp bead and one half of toggle clasp crimp closed. Repeat for other side.
- STEP 6: Attach crimp covers.