

SWAROVSKI



BRACELET "007"

Materials

Swarovski crystals

Product Group	Article No.	Amount	Size	Color	Color Code
Beads	5542	4 pcs.	8 mm	Crystal	001
Beads	5542	3 pcs.	11 mm	Crystal	001

Supplies: 7 Medium Hammertone Link TierraCast® 94-3086-13 7 Large Hammertone Link TierraCast® 94-3087-13
1 Large Tapered Clasp TierraCast® 94-6067-13 7 Rectangle Hammertone Button TierraCast® 94-6561-13
44 8 mm Round jump Rings TierraCast® 01-0020-13 7 2" Head Pins TierraCast® 01-0028-13

Instructions

- STEP 1: Using one headpin slide on one Swarovski Bead art. 5542 8mm Crystal point side up. Wire wrap to close and set aside. Repeat 3 more times.
- STEP 2: Using one headpin slide on one Bead art. 5542 11 mm Crystal point side up. Wire wrap to close and set aside. Repeat 2 more times.
- STEP 3: To make the button linked bracelet begin by linking two jump rings to a third jump ring. Then capture the two loose jump rings with one more jump ring and attach this last jump ring to one hole in the rectangle Hammertone button. Starting with the second hole in the button repeat the jump ring pattern linking together the other 6 buttons.
- STEP 4: Looking to the left side of the bracelet and using the section with the double jump ring section link on the following with additional jump rings: one medium Hammertone link, one Bead created in step 1, and one large Hammertone link.
- STEP 5: Moving to the next section with double jump rings link on the following with additional jump rings: one medium Hammertone link, one Bead created in step 2, and one large Hammertone link.
- STEP 6: Repeat steps 4 and 5 until all Beads and links are attached.
- STEP 7: Attach toggle and ring to either side of the bracelet to finish with jump rings.