



MINI PROJECT HALLOWEEN BAT PENDANT EARRINGS

Materials

SWAROVSKI ELEMENTS

Product Group	Article No.	Amount	Size	Color	Color Code
Pendants	6902	2 pcs.	16.5x25mm	Jet	280
Flat Backs No Hotfix (round) 2028		4 pcs.	SS10	Light Siam	227

Supplies: 2 gun metal 8mm jump rings 2 gun metal 4mm jump rings 2 gun metal ear wires
 Beeswax Toothpicks Two-part epoxy glue
 Acetone Q-tips (10 minute or longer curing time)

Instructions

- STEP 1: Mix 2 part epoxy glue as instructed on package.
- STEP 2: Using a toothpick, place 2 small dots of mixed glue near center of Pendant from the SWAROVSKI ELEMENTS assortment (see picture for correct way to lay Pendant.)
- STEP 3: Apply a small amount of beeswax to the end of a clean toothpick. Pick up one Swarovski Flat Back art. 2028 using the tip of the beeswax toothpick and place on one of the glue dots. Repeat with second Flat Back art. 2028.
- STEP 4: Allow glue to dry for recommended time on glue package. Clean any glue residue with a Q-tip dipped in acetone.
- STEP 5: Open both of the 8mm jump rings using flat nose pliers.
- STEP 6: Attach one 8mm jump ring to the hole in the top of the Swarovski Pendant and then to the closed 4mm jump ring. Close the 8mm jump ring to secure.
- STEP 7: Open the 4mm jump ring and attach to the ear wire.
- STEP 8: Repeat steps 7 – 8 for second earring.