



MINI PROJECT "CHRISTMAS 2011"

A CHARMING CHRISTMAS

- Supplies:
- 4 silver headpins 2"
 - 1 wreath and bow clasp
 - 2 nutcracker charms
 - 1 Christmas tree charm
 - 1 bow bead
 - 4 Beadalon C-Crimp cord ends
 - 6" curb chain silver
 - 1 foot 3mm red suede
 - 5 oval jump rings
 - 1 candy cane charm
 - 1 Frosty charm
 - 1 wing bead
 - 10 jump rings 4mm
 - 6" small cable chain silver
 - 1 foot 20 gauge Artistic Wire silver

Candy Cane Charm

| | | | | | |
|-------|------|--------|------|------------------------------|------------|
| Beads | 5328 | 2 pcs. | 3 mm | Crystal | 001 |
| Beads | 5328 | 5 pcs. | 4 mm | Crystal | 001 |
| Beads | 5328 | 6 pcs. | 4 mm | Dark Red coral or Light Siam | 396 or 227 |

Candy Cane Charms

- STEP 1: String onto one headpin: one Bead art. 5328 3 mm Crystal, one Bead art. 5328 4 mm Dark Red Coral, one Bead art. 5328 4 mm Crystal, one jump ring, one Bead art. 5328 4 mm Dark Red Coral, one Bead art. 5328 4 mm Crystal, one Bead art. 5328 4 mm Dark Red Coral, one Bead art. 5328 4 mm Crystal, one silver bow bead finding (upside down), one Bead art. 5328 Dark Red Cora, one Bead art. 5328 4 mm Crystal, one Bead art. 5328 4 mm Dark Red Coral, one Bead art. 5328 4 mm Crystal, one Bead art. 5328 4 mm Dark Red Coral, and one Bead art. 5238 3 mm Crystal.
- STEP 2: Turn a small loop at end of headpin.
- STEP 3: Hold beaded headpin so the loop is at bottom. Bend headpin to form a "hook". The headpin should start to bend at the second Swarovski Bead art. 5328 4 mm Crystal after the bow.

| Product Group | Article No. | Amount | Size | Color | Color Code |
|--------------------------|------------------|---------|--------|--------------------------------|------------|
| Toy Soldier Charm | | | | | |
| Beads | 5000 | 1 pc. | 8 mm | Crystal | 001 |
| Beads | 5328 | 1 pc. | 4 mm | Crystal Metallic Light Gold 2x | 001 MLG2 |
| Beads | 5328 | 19 pcs. | 4 mm | Dark Red Coral | 396 |
| Beads | 5328 | 8 pcs. | 4 mm | White Alabaster | 281 |
| Beads | 5500 | 1 pc. | 9x6 mm | Jet | 280 |
| Beads | 5601 | 2 pcs. | 4 mm | Jet | 280 |
| Rondelles | 4720/101/012/001 | 1 pc. | 5.5 mm | Crystal | 001 |
| Rondelles | 77505P16000 | 2 pcs. | 5 mm | Montana (gold plated) | 207 |

Toy Soldier Charm

- STEP 1: Slip on (2) Beads art. 5601 4 mm Jet and (2) Beads art. 5328 4 mm White Alabaster onto (1) 18" piece of wire.
- STEP 2: Keeping SWAROVSKI ELEMENTS in center of wire, take one end of wire and weave back through the two Beads in White Alabaster keeping tension on the wire (Note: wire tails should exit beads in opposite directions).
- STEP 3: Add (2) Beads art. 5328 4 mm White Alabaster onto one wire tail. Take the opposite wire tail and weave back through the two SWAROVSKI ELEMENTS just added (Note: wire tails should exit in opposite directions). Repeat this step once.
- STEP 4: Add (1) Bead art. 5328 Dark Red Coral, (1) Bead art. 5328 Crystal Metallic Light Gold 2x and (1) Bead art. 5328 Dark Red Coral onto one side of the wire. Take the opposite wire and weave back through the SWAROVSKI ELEMENTS just added (Note: wire tails should exit Beads in opposite directions). Repeat 2 more times using (3) Beads art. 5328 Dark Red Coral for each row.
- STEP 5: Using wire on right side, make a loop ~4 mm in diameter. Repeat on left side (Note: the loops should sit at right angles to the body). The loops are used as a socket for the arms.
- STEP 6: Slip onto each wire tail (1) Bead art. 5328 Dark Red Coral (Note: do not pull on the wire, the loop shape must be maintained).
- STEP 7: Keeping both wires together slide on (1) Bead art. 5000 8 mm Crystal, (1) Swarovski Rondelle 5.5 mm Jet and (1) Bead art. 5500 9x6 mm Jet (Note: keeping the point side facing the Rondelle).
- STEP 8: Keeping both wires together, create a wire wrapped loop.
- STEP 9: Create the arms using (1) balled head pin, load on (1) Bead art. 5328 Dark Red Coral, (1) Swarovski Rondelle 5 mm Montana and slide the head pin through the 4 mm loop, coming off the shoulder, made in step 5 (Note: the open end of the head pin should be pointing away from the head of the soldier). Add (3) Beads art. 5328 Dark Red Coral and (1) Bead art. 5328 White Alabaster. Keeping the SWAROVSKI ELEMENTS tucked next to each other, cut off the remaining wire ~5 - 6 mm from the last Bead. Turn a loop and flatten if desired. Repeat for the other arm.
- STEP 10: Slip (1) Bead art. 5328 Dark Red Coral onto an add-a-bead ear wire and turn a loop. Open loop and attach to the wrapped loop on the toy soldier.

| Christmas Tree Charm | | | | | |
|----------------------|------|-------|-------|--------------------------------|----------|
| Sew-on Stones | 3700 | 1 pc. | 6 mm | Fern Green | 291 |
| Sew-on Stones | 3700 | 1 pc. | 8 mm | Fern Green | 291 |
| Sew-on Stones | 3700 | 1 pc. | 10 mm | Fern Green | 291 |
| Sew-on Stones | 3700 | 1 pc. | 12 mm | Fern Green | 291 |
| Sew-on Stones | 3700 | 1 pc. | 14 mm | Fern Green | 291 |
| Beads | 5328 | 1 pc. | 4 mm | Crystal Metallic Light Gold 2x | 001 MLG2 |
| Beads | 5601 | 1 pc. | 4 mm | Siam | 08 |

Christmas Tree Charm

STEP 1: Slip onto one headpin: one Swarovski Bead art. 5601 4 mm Siam, one Sew-on Stone art. 3700 14 mm Fern Green, one Sew-on Stone art. 3700 12 mm Fern Green, one Sew-on Stone art. 3700 10 mm Fern Green, one Sew-on Stone art. 3700 8 mm Fern Green, one Sew-on Stone art. 3700 6 mm Fern Green, one Bead art. 5328 4 mm Crystal Metallic Light Gold 2x.

STEP 2: Wire wrap and set aside.

| Snowman Charm | | | | | |
|---------------|--------------|-------|-------|---------|-----|
| Sew-on Stones | 3128 | 1 pc. | 8 mm | Jet | 280 |
| Beads | 5000 | 1 pc. | 6 mm | Crystal | 001 |
| Beads | 5000 | 1 pc. | 8 mm | Crystal | 001 |
| Beads | 5000 | 1 pc. | 10 mm | Crystal | 001 |
| Beads | 5601 | 1 pc. | 4 mm | Jet | 280 |
| Rondelles | 77504 P13000 | 1 pc. | 4 mm | Emerald | 205 |

Snowman Charm

STEP 1: Slip onto one headpin: one Bead art. 5000 10 mm Crystal, one Bead art. 5000 8 mm Crystal, one Swarovski Rondelle Emerald, one Bead art. 5000 6 mm Crystal, one Sew-on Stone art. 3128 8 mm Jet, and one 5601 4 mm Jet.

STEP 2: Wire wrap and set aside.

| Artemis Angel Charm | | | | | |
|---------------------|--------------|--------|-------|---------|-----|
| Beads | 5000 | 1 pc. | 6 mm | Crystal | 001 |
| Beads | 5040 | 1 pc. | 6 mm | Crystal | 001 |
| Beads | 5540 | 1 pc. | 12 mm | Crystal | 001 |
| Rondelles | 77504 P13000 | 1 pc. | 4 mm | Crystal | 001 |
| Beads | 5714 | 6 pcs. | 12 mm | Crystal | 001 |

Artemis Angel Charm

STEP 1: String onto one headpin: one Bead art. 5040 6 mm Crystal, one Bead art. 5540 12 mm Crystal, one silver wing bead finding, one Bead art. 5000 6 mm Crystal, and one Swarovski Rondelle 4 mm Crystal.

STEP 2: Turn a small loop at end of headpin.

To Assemble Necklace

- STEP 1: Cut six 1.5" pieces of 20 gauge wire. Cut six 1" piece of small cable chain. Note: each piece should have the same link count.
- STEP 2: Using cut wire create a simple loop, slide on one Bead art. 5714 and create a second simple loop. Repeat times five and set aside.
- STEP 3: Open one 4mm jump ring and attach one piece of cable chain and one TierraCast Charm; close jump ring. Open one loop of star component and attach to opposite end of chain. Repeat for remaining 5 charms. Set aside.
- STEP 4: Attach an oval jump ring to each crystal charm. Set aside.
- STEP 5: Lay out curb chain and attach all metal and crystal charm components at desired intervals. (Note: remember to hold chain in same position so that each charm will hang on the same side of the chain. Hint: For ease of charm attachment begin in center of chain for attaching.)
- STEP 6: Cut suede lace into two even pieces for your finished desired length of necklace. Attach a cord end to each of the four ends of the suede lace.
- STEP 7: Attach one 4mm round jump ring to one cord end and one end of curb chain. Repeat for opposite side.
- STEP 8: Attach a 4mm round jump ring to the remaining ends of the suede lace. Before closing jump rings attach one half of the wreath toggle set to each side. Close jump rings.