



MINI PROJECT FALL
CORNUCOPIA
EARRINGS

Materials

SWAROVSKI ELEMENTS

Product Group	Article No.	Amount	Size	Color	Color Code
Beads	5540	2 pcs.	17 mm	Crystal Copper (001 COP)	
Beads	5328	36 pcs.	2.5 mm	A variety of the following colors: Olivine (228), Crystal Red Magma (001 REDM), Crystal Golden Shadow (001 GSHA), Crystal Copper (001 COP), Topaz (203), Smoked Topaz (220), Crystal Metallic Light Gold 2x (001 MLG2)	
Beads	5328	36 pcs.	3 mm	A variety of the same colors as above.	
Beads	5000	36 pcs.	3 mm	A variety of the same colors as above.	
Beads	5040	18 pcs.	4 mm	Crystal Red Magma (001 REDM)	
Crystal Pearls	5810	54 pcs.	3 mm	Crystal Copper (001 159), Crystal Bright Gold (001 306), Crystal Dark Green (001 814), Crystal Maroon (001 388), Crystal Bright Gold (001 306)	
Crystal Pearls	5810	36 pcs.	5 mm	A variety of the same colors used above	
Pendants	6007	18 pcs.	7 x 4 mm	Crystal Copper (001 COP) or Topaz (203)	

Supplies: 6 gun metal jump rings 6mm
 6" gun metal chain
 6" 24 gauge wire

2 gun metal ear wires
 28 gauge craft wire 1 spool

Continuation on next page

- STEP 1: Make all wire components prior to assembly (12 for each side) using whatever combination of Beads and Pearls from the SWAROVSKI ELEMENTS assortment you would like.
- STEP 2: Cut a 5" piece of 28 gauge wire. Bend it in a U shape, keeping one end longer than the other. String 12 Swarovski Beads and Crystal Pearls onto the wire (use a variety of colors and sizes of the XILION Beads art. 5328 2.5mm & 3mm, round Beads 3mm, Crystal Pearls 3mm and 5mm and use 1 Swarovski Pendant art. 6007 in the middle of the strand).
- STEP 3: Cross the short wire end over the long end and twist the wires together. Snip off the short wire end (keep the long wire end intact).
- STEP 4: Repeat steps 2 & 3 seventeen more times to make 18 beaded wires (9 for each earring).
- STEP 5: Cut a 6" piece of 28 gauge wire and string on one Swarovski Bead art. 5040 4mm. Keeping the Bead in the middle of the wire, twist the two ends together 3-4 times.
- STEP 6: String one more Swarovski Bead art. 5040 4mm onto one wire end leaving about 10mm of wire between this Bead and the one from the previous step. Coil the 10mm of wire between the two Beads so the wire is a spiral between the two Beads.
- STEP 7: String another Swarovski Bead art. 5040 4mm onto the other wire end, again leaving 10mm of wire between the two Beads. Coil the wire between the Beads as done in step 6.
- STEP 8: Twist the two tail ends of the wire together 3-4 times. Cut off the short end and leave the long wire end.
- STEP 9: Repeat steps 5-8 five more times (you will have 3 strands for each earring).
- STEP 10: Cut the chain into 4 equal lengths. Open the 4 jump rings and attach one piece of chain to each. Close the jump rings securely.
- STEP 11: Pick up 9 beaded wires from steps 1 – 3 and 3 beaded wires from steps 5 – 8. Holding the wires together, slide them through one of the jump rings with the attached chain.
- STEP 12: Slide the wires through the Swarovski Bead art. 5540 going in the wide end and coming out the narrow end. Slide a jump ring with attached wire onto the twelve wire ends.
- STEP 13: Cut a 2" piece of 24 gauge wire. Hold the 2" piece of wire along the length of the Swarovski Bead art. 5540. At the point where the 24 gauge wire meets the twelve 28 gauge wires begin to wrap a coil around the 28 gauge wires (after the jump ring) with the 24 gauge wire. Wrap it 3-4 times, keeping them tight.
- STEP 14: When the 28 gauge wires are held tight, cut off the ends of the 24 gauge wire. Tuck in any loose ends and then cut off the excess 28 gauge wires.
- STEP 15: Open a jump ring and attach the two chain ends and the ear wire to the jump ring. Close the jump ring to secure. You can cut the chain to make a shorter earring if desired.
- STEP 16: Repeat steps 11 – 15 for the other earring.



MINI PROJECT FALL BEADED PUMPKIN EARRINGS

Materials

SWAROVSKI ELEMENTS

Product Group	Article No.	Amount	Size	Color	Color Code
Beads	5328	94 pcs.	2.5 mm	Olivine	228
Beads	5328	2 pcs.	5 mm	Khaki	550
Beads	5328	2 pcs.	4 mm	Khaki	550
Beads	5005	2 pcs.	16 mm	Crystal Red Magma	001 REDM

Supplies: 2 Silver head pins 2 Silver ear wires 2 feet 24 gauge wire

Instructions

- STEP 1: To create the small leaf, cut a 4" piece of wire and string 10 XILION Beads art. 5328 2.5mm Olivine.
- STEP 2: Bend the wire in the shape of a horseshoe, keeping the Beads in the center.
- STEP 3: Overlap the ends of the wire and create a wire wrapped loop using both tails.
- STEP 4: Repeat steps 1 – 3 for a second small leaf.
- STEP 5: To create the large leaf, repeat steps 1 – 3, except cut a 5" piece of wire and string on 14 XILION Beads (5328 2.5mm Olivine). Repeat for a second large leaf.
- STEP 6: To create the curly vines, cut a 6" piece of wire and make a small 2mm closed loop on one end and flatten the loop (this will prevent Beads from falling off wire).
- STEP 7: String 23 XILION Beads art. 5328 2.5mm Olivine onto the wire.

[Continuation on next page](#)

"Beaded Pumpkin Earrings", page 2

- STEP 8: Curl the beaded wire around a skewer, chop stick or other thin stick, keeping the Beads pushed toward the looped end.
- STEP 9: When you reach the end of the beaded part of the wire, wrap a loop with the remaining wire. Repeat for a second vine.
- STEP 10: To assemble the earring, slide one Swarovski Bead art. 5005 16mm Crystal Red Magma onto a headpin.
- STEP 11: Slide the large leaf onto the headpin and then add the small leaf using the loops formed.
- STEP 12: Add one XILION Bead 5mm Khaki, one of the curly vines (through the loop made) and one XILION Bead 4mm Khaki.
- STEP 13: Wire wrap a loop on the end of the headpin and attach the ear wire to the loop.
- STEP 14: Repeat steps 10 – 13 for second earring.