



MINI PROJECT HALLOWEEN GHOST PENDANT NECKLACE

Materials

SWAROVSKI ELEMENTS

Product Group	Article No.	Amount	Size	Color	Color Code
Pendants	6900	1 pc.	30 x 45 mm	Crystal	001
Flat Backs No Hotfix	2797	1 pc.	8 x 4 mm	Crystal F	001
Flat Backs No Hotfix (round) 2028		2 pcs.	SS14	Jet	280

Supplies: 24" White silk cord
Beeswax
Acetone
1 Silver clasp

2 silver cord ends
Toothpicks
Q-tips

2 silver 4mm jump rings
Two-part epoxy glue
(10 minute or longer curing time)

Instructions

- STEP 1: Mix 2 part epoxy glue as instructed on package.
- STEP 2: Using a toothpick, place 1 small dot of mixed glue near bottom of Pendant from the SWAROVSKI ELEMENTS assortment (see picture for correct way to lay Pendant).
- STEP 3: Apply a small amount of beeswax to the end of a clean toothpick. Pick up the Flat Back art. 2797 using the tip of the beeswax toothpick and place on the glue dot to make the mouth.
- STEP 4: Apply two small dots of glue above the "mouth" and using the beeswax toothpick apply the two Swarovski Flat Backs art. 2028 for the eyes.
- STEP 5: Slide silk cord through hole in Pendant so the cord is even on both ends.
- STEP 6: Make a loop with both cords near the hole of the pendant and slide the two free ends through it. Pull the ends tight to form a knot.
- STEP 7: Attach the cord ends to each free end using flat nose pliers.
- STEP 8: Open the two 4mm jump rings using pliers and attach one to each cord end.
- STEP 9: Attach one part of the clasp to each end and close the jump rings.
- STEP 10: Allow glue to dry for 24 hours. Clean any glue residue with a Q-tip dipped in acetone.



MINI PROJECT HALLOWEEN GHOST PENDANT EARRINGS

Materials

SWAROVSKI ELEMENTS

Product Group	Article No.	Amount	Size	Color	Color Code
Pendants	6900	2 pcs.	13.5 x 20mm	Crystal	001
Flat Backs No Hotfix (round) 2028		4 pcs.	SS7	Jet	280

Supplies: 2 silver 8mm jump rings
Beeswax
Acetone

2 silver 4mm jump rings
Toothpicks
Q-tips

2 silver ear wires
Two-part epoxy glue
(10 minute or longer curing time)

Instructions

- STEP 1: Mix 2 part epoxy glue as instructed on package.
- STEP 2: Using a toothpick, place 2 small dots of mixed glue near right center of one Pendant from the SWAROVSKI ELEMENTS assortment and left center of the other (see picture for correct way to lay Pendant).
- STEP 3: Apply a small amount of beeswax to the end of a clean toothpick. Pick up one Swarovski Flat Back art. 2028 using the tip of the beeswax toothpick and place on one of the glue dots. Repeat with second Flat Back art. 2028.
- STEP 4: Allow glue to dry for recommended time on glue package. Clean any glue residue with a Q-tip dipped in acetone.
- STEP 5: Open both of the 8mm jump rings using flat nose pliers.
- STEP 6: Attach one 8mm jump ring to the hole in the top of the Swarovski Pendant and then to the closed 4mm jump ring. Close the 8mm jump ring to secure.
- STEP 7: Open the 4mm jump ring and attach to the ear wire.
- STEP 8: Repeat steps 7-8 for second earring