



MINI PROJECT "CHRISTMAS 2011"

# PARTRIDGE IN A PEAR TREE EARRINGS

## Materials

### SWAROVSKI ELEMENTS

Product Group	Article No.	Amount	Size	Color	Color Code
Sew-on Stones	3700	2 pcs.	6 mm	Fern Green	291
Sew-on Stones	3700	2 pcs.	8 mm	Fern Green	291
Sew-on Stones	3700	2 pcs.	10 mm	Fern Green	291
Sew-on Stones	3700	2 pcs.	12 mm	Fern Green	291
Sew-on Stones	3700	2 pcs.	14 mm	Fern Green	291
Beads	5328	2 pcs.	4 mm	Crystal Metallic Light Gold 2x	001 MLG2
Beads	5328	2 pcs.	4 mm	Topaz	203
Beads	5500	2 pcs.	9x6 mm	Topaz	203
Beads	5601	2 pcs.	4 mm	Siam	208

Supplies: 4 TierraCast Silver headpins 2" (01-0029-01)  
2 TierraCast Silver ear wires (90-1120-00)

2 TierraCast Paloma connector (94-3129-12)

## Instructions

- STEP 1:** Using one headpin, slip on one Swarovski Bead art. 5601 4mm Siam, one Sew-on Stone art. 3700 14 mm Fern Green, one Sew-on Stone art. 3700 12 mm Fern Green, one Sew-on Stone art. 3700 10 mm Fern Green, one Sew-on Stone art. 3700 8 mm Fern Green, one Sew-on Stone art. 3700 6 mm Fern Green and one Bead art. 5328 4 mm Metallic Light Gold 2x. Wire wrap a loop on the headpin (Note: before closing off the loop, attach the loop to the bottom hole on the Paloma connector making sure to orient the connector in the correct direction). Repeat this step for the other pair.
- STEP 2:** Using one headpin, slip on one Swarovski Bead art. 5500 9x6 mm Topaz. Wire wrap a loop on the headpin (Note: before closing off the loop attach to the wire wrapped loop from step 1). Repeat this step for the other pair.
- STEP 3:** Using the add-a-bead ear wire, load on one Swarovski Bead art. 5328 4 mm Topaz. Turn a simple loop on the earwire. Open up the loop and attach to the top hole of the Paloma connector. Repeat this step for the other pair.