



## MINI PROJECT HALLOWEEN JACK-O-LANTERN PENDANT NECKLACE

### Materials

#### SWAROVSKI ELEMENTS

| Product Group        | Article No. | Amount | Size     | Color          | Color Code |
|----------------------|-------------|--------|----------|----------------|------------|
| Pendants             | 6621        | 2 pcs. | 18mm     | Crystal Copper | 001 COP    |
| Flat Backs No Hotfix | 2797        | 6 pcs. | 8 x 4 mm | Olivine        | 228        |

Supplies: 24" Black Silk Cord  
Beeswax  
Acetone

1x 6 mm silver or gun metal jump ring  
Toothpicks  
Q-tips

1 silver or gun metal jewelry tag  
Two-part epoxy glue  
(10 minute or longer curing time)

### Instructions

- STEP 1: Mix 2 part epoxy glue as instructed on package.
- STEP 2: Using a toothpick, place 5 small dots of mixed glue alternately placed near the bottom of one of the Swarovski Flat Backs art. 2035 30mm.
- STEP 3: Apply a small amount of beeswax to the end of a clean toothpick. Pick up one of the Flat Backs art. 2400 using the tip of the beeswax toothpick and place on one of the glue dots. Repeat for the other 4 Flat Backs.
- STEP 4: Repeat steps 2 and 3 to glue on triangular Swarovski Flat Backs for eyes and nose.
- STEP 5: Spread glue on back of the other Flat Back art. 2035 30mm. Lay the flat bail on the back so the loop is above the top of the crystal. Lay the embellished Flat Backs art. 2035 from steps 2 – 4 on top of the Flat Backs art. 2035 with the glue. Let dry for the amount of time stated in the instructions on the glue package.
- STEP 6: Clean any glue residue with a Q-tip dipped in acetone.
- STEP 7: Open the 6mm jump ring and attach it to the loop in the bail. Close the jump ring to secure.
- STEP 8: Slide silk cord through the jump ring so the cord is even on both ends. Tie the cord to the desired length.



## MINI PROJECT HALLOWEEN

# JACK-O-LANTERN EARRINGS

### Materials

#### SWAROVSKI ELEMENTS

| Product Group                 | Article No. | Amount  | Size  | Color             | Color Code |
|-------------------------------|-------------|---------|-------|-------------------|------------|
| Pendants                      | 6621        | 2 pcs.  | 18 mm | Crystal Red Magma | 001 REDM   |
| Flat Backs No Hotfix (square) | 2400        | 6 pcs.  | 3 mm  | Jet               | 280        |
| Flat Backs No Hotfix (round)  | 2028        | 10 pcs. | SS7   | Jet               | 280        |

Supplies: 2 gun metal 6mm jump rings      2 gun metal 4mm jump rings      2 gun metal ear wires  
 Beeswax      Toothpicks      Two-part epoxy glue  
 Acetone      Q-tips      (10 minute or longer curing time)

### Instructions

- STEP 1: Mix 2 part epoxy glue as instructed on package.
- STEP 2: Using a toothpick, place 5 small dots of mixed glue evenly spaced onto the bottom of Pendant from the SWAROVSKI ELEMENTS assortment to form the mouth.
- STEP 3: Apply a small amount of beeswax to the end of a clean toothpick. Pick up one of the Flat Backs art. 2028 ss7 using the tip of the beeswax toothpick and place onto one of the glue dots. Repeat this step for the other 4 Swarovski Flat Backs art. 2028.
- STEP 4: Place 2 glue dots near top of Pendant for eyes and one in center for nose. Repeat step 3 using the Flat Backs art. 2400.
- STEP 5: Repeat steps 3 and 4 for the second earring.
- STEP 6: Allow glue to dry for recommended time on glue package. Clean any glue residue with a Q-tip dipped in acetone.
- STEP 7: Open both of the 6mm jump rings using flat nose pliers.
- STEP 8: Attach one 6mm jump ring to the hole in the top of the Swarovski Pendant and then to the closed 4mm jump ring. Close the 6mm jump ring to secure.
- STEP 9: Open the 4mm jump ring and attach to the ear wire.
- STEP 10: Repeat steps 7 – 8 for second earring.